



POCKET BALANCE (0.1g) 100006

Smaller than a bi-fold wallet, this digital balance easily slides into a shirt pocket. The protective cover folds over Pocket Balance for travel. During operation the cover slides out of the way to reveal a stainless steel weighting platform. Features six units of measure, auto power off and a tare function. The display indicates overload, low battery, stability and freezes automatically when stable for 2 seconds. If weight is added or subtracted the balance resumes measuring. Automatically calibrates to 100 grams, weight (included). Comes with mounted tweezers, 100 gram calibration weight, 2 button cell batteries, pouch, and instructions.

Weight: 4oz (121g) including batteries. Dim: 4 1/2" x 3 x 3/4" (115 x 75 x 20mm).

Units	Range	Resolution
Grams	200	0.1
Ounces	7	0.001
Pennyweight	125	0.1
Troy Ounces	6	0.001
Carat	1000	0.5
Grain	3000	0.1