

**SUGAR REFRACTOMETERS 0~10%
300012**

A magnified scale with high resolution for precise measurement of industrial fluids such as cutting oils, and fruit juices with low sugar concentrations.

Dim: 8¼" x 1½"
Weight: 8 oz
Range: 0~10% brix
Resolution: 0.1%
Accuracy: 0.1%



With certificate of calibration
300012C

**SUGAR REFRACTOMETER w/ATC
0~10% 300013**

Same as above but this refractometer comes with automatic temperature compensation (ATC), which makes manual temperature corrections unnecessary.

Dim: 8¼" x 1½"
Weight: 8½ oz
Range: 0~10% brix
Resolution: 0.1%
Accuracy: 0.1%



With certificate of calibration
840028C