



MINI SOUND METER 840014

This **tiny** meter is packed with features, yet its small and light enough to be carried in your shirt pocket. Choose from fast or slow time weightings, **min-max readings** and A or C decibel frequency weighting scales. All of these settings are simultaneously indicated on the display, as are out of range sound levels. Also features AC output. **Readings are extremely stable and reliable.** Meets IEC651 and ANSI S1.4 specifications for a type 2 sound meter. Covers the 30-130 dB range with 0.1 dB resolution and an **accuracy of ± 1 dB** (Ref. 94dB@1KHz). Can be calibrated, in compliance with OSHA, using Acoustical Calibrator 840031 or equivalent. Comes ready to use with a windscreen, calibration tool, instructions and a 9V battery, which provides approximately 60 hours of continuous use.

Dim: 9" x 2" x 1¼" (232 x 54 x 34mm)

Weight: 6½ oz (180g) with battery



With N.I.S.T. traceable certificate of calibration 840014C

OPTIONAL ACCESSORIES

840031 2 Pt. Acoustical Calibrator

840091 Windscreen Replacement

